

Installation of Jim's S50/S83 Spacers

Note: Put a towel or blanket on your gas tank to protect your paint from being damaged. You may want to mark your bars to make it easy to center later.

1. Remove the plastic caps from the riser topbolts and remove the top half of the risers. Lay the bars on the tank or have a friend hold them.
2. Remove the Metric Allen bolts holding the risers to the bars. These are in there with Loctite and are tight.
3. Install the spacers on to the riser bars and then put the top risers on using the Metric Allen bolts supplied.
4. Install the bars back on the risers. Make sure they are lined up straight.
5. Tighten the riser tops and install the plastic caps.
6. Check your cables, wires and lines for binding.