

## Installation of Ducati Spacers

1. Remove the tops of both risers and move the handlebars out of the way.  
**Caution: Try not to turn your handlebars upside down. Air from the brake reservoir may get into your brake line causing front brake problems. Put a towel or blanket on your bike to protect it.**
2. Remove the two allen bolts that hold the risers on.
3. **Refer to figure.** Install the new allen bolts through the risers, through Jim's Spacers and screw into the triple tree. Tighten to Factory specs of 35Nm.
4. Install the handlebars in the risers and install the top part of the risers. Tighten to Factory spec of 25Nm.
5. Double check that all fasteners are tight.

